

Увага!

Для коректної та стабільної роботи сигналізатора клювання перед експлуатацією необхідно кожне регульовальне колесо декілька разів обернути від упору до упору.

Сигналізатор

1. Включення. Переведіть тумблер, прозвучить дворазовий сигнал. Ближнє верхній індикатор, бігучий вогник на основному індикаторі зробить оборот за годинниковою стрілкою.
2. Регулювання гучності. Повертайте колесо V для регулювання гучності. Доступні 7 рівнів + тихий режим. Основний індикатор і шкала на колесі V відображають рівень гучності. Крім того, сигнал демонструє рівень гучності під час регулювання.
3. Налаштування тону. Повертайте колесо T для налаштування тону. Доступні 8 типів. Основний індикатор і шкала на колесі T показують, який тип тону обрано. Крім того, сигнал демонструє тип тону, який обрано.
4. Налаштування чутливості. Повертайте колесо S для налаштування чутливості. Доступні 8 рівнів. Основний індикатор і шкала на колесі S відображають рівень чутливості. Під час налаштування звучить сигнал.
5. Налаштування кольору. Повертайте колесо C для вибору кольору. Доступні 6 кольорів. Основний індикатор, а також шкала на колесі C відображають, який колір обрано. Під час налаштування звучить сигнал.
6. Попередження про падіння напруги. Перший вогник основного індикатора буде блимати кожні 5 секунд. Замініть батарею за першої нагоди.
7. Індикація клювань від берега і в берег відбувається за допомогою різних звукових сигналів і різного напрямку обертання біжить вогню на основному індикаторі.
8. Функція пам'яті. Верхні індикаторні вогні горять 20 секунд після клювання. Якщо клювання була в напрямку берега, то правий індикатор блимає.
9. Тихий режим. Натисніть кнопку M і утримуйте 2 секунди для включення / вимикання тихого режиму. Протягом однієї хвилини сигналізатор не подаватиме звуковий сигнал і не буде передавати сигнал на ресивер - поки ви будете встановлювати вудлице. При виключенні сигналізатора режим вимикається.
10. Режим зв'язку. За допомогою кнопок M і F одночасно для включення / вимикання режиму. Коли функція активована, сигналізатор кожні 5 секунд передає на ресивер сигнал. Якщо сигнал не надходить з якої-небудь причини (низький рівень заряду, несправність, крадіжка), ресивер дає спеціальний звуковий сигнал, індикатор, відповідний до сигналізатора, загоряється. При виключенні сигналізатора режим вимикається.
11. Функція анти-крадіжка. Натисніть кнопку F для включення / вимкнення режиму, пролунає подвійний звуковий сигнал. Тепер якщо хтось зніме вудлице з сигналізатора, він передасть сигнал на ресивер. Ресивер дасть переривчастий звуковий сигнал; відповідний до сигналізатора індикатор буде блимати. При виключенні сигналізатора режим вимикається.
12. Для виключення переведіть тумблер.

Ресивер

1. Включення. Повертайте колесо V за годинниковою стрілкою (до поділки 1) для включення приймача. Всі індикатори засвітяться 2 рази і пролунає дворазовий звуковий сигнал.
2. Регулювання гучності. Повертайте колесо V для регулювання гучності. Доступні 5 рівнів + тихий режим.
3. Вибір тону. На ресивері автоматично встановлюється тон, який обрано на сигналізаторі.
4. Вибір кольору. Ресивер укомплектовано світлодіодами Multi-Color. Колір, що встановлено на сигналізаторі, автоматично встановлюється на ресивері.
5. Вибір режиму. Натисніть кнопку Z для включення / вимкнення режиму. Він може працювати без звуку (поділка 2 на колесі V) і зі звуком (інші поділки).
6. Режим синхронізації. Натисніть кнопку A і утримуйте 3 секунди, відпустіть після звукового сигналу. Загориться перший світлодіод на індикаторі. Обертайте ролик сигналізатора, ресивер прийме його сигнал. Якщо на сигналізаторі встановлений, наприклад, синій колір, індикатор на ресивері також стане синім. Пролунає звуковий сигнал. Потім включиться другий індикатор. Обертайте ролик другого сигналізатора, щоб повторити попередню операцію. Натисніть кнопку R або Z для виходу з режиму. Режим синхронізації вимкнеться автоматично, якщо не виконувати жодних дій протягом 12 секунд.
7. Видалення кодів. Натисніть кнопку A і утримуйте 3 секунди. Після звукового сигналу утримуйте ще 3 секунди. Після триразового звукового сигналу всі коди будуть стерті.
8. Індикація клювань від берега і в берег відбувається за допомогою різних звукових сигналів. Відповідний до сигналізатора індикатор блимає.
9. Функція пам'яті. Якщо натиснути кнопку R, загориться індикатор, відповідний сигналізатора, на якому було останнє спрацьовування. Якщо клювання було в напрямку берега, індикатор буде блимати.
10. Попередження про падіння напруги. Якщо напруга впаде нижче 6,3 В, перший світлодіод почне блимати через кожні 5 секунд. Замініть батарею за першої нагоди.
11. Вимкнення. Повертайте колесо V до поділки 0.

Технічні характеристики

Батареї: 6F22 (9 В) – сигналізатори і ресивер

Частота сигналу: 433 МГц

Максимальна дистанція передачі: 200–220 м

Пилозахист та вологозахист (IP 66)

Якщо ви не використовуєте пристрої тривалий час, вийміть, будь ласка, батарейки!

Attention!

For the correct and stable operation of the bite alarm before the first use rotate each adjusting wheel several times from stop to stop!

Bite Alarm

1. Power on. Press the toggle switch and the horn will beep twice. The top indicator will flash once and the light on the main indicator will turn clockwise.
2. Volume Adjustment. Rotate the V wheel to adjust the volume. 7 levels of volume + silent mode are available to adjust. The main indicator and the scale on the V wheel indicate the volume level. Besides that, the horn demonstrates the sound volume when adjusting.
3. Tone selection. Rotate the T wheel to adjust the tone. 8 types of tone are available to adjust. The main indicator and the scale on the T wheel indicate which type is chosen. Besides that, the horn demonstrates the tone when adjusting.
4. Sensitivity adjustment. Rotate the S wheel to adjust the sensitivity. 8 levels of sensitivity are available to adjust. The main indicator and the scale on the S wheel indicate the sensitivity level. The horn beeps when adjusting.
5. Color select. Rotate the C wheel to select the color. 6 colors are available. The main indicator and the scale on the C wheel indicate which color is chosen. The horn beeps when adjusting.
6. Low voltage alarm. The first indicator light of the main indicator will flash every 5 seconds. Replace the battery as soon as possible.
7. Drop-back function. The alarm indicates drop/back bites with different sounds and different directions of running light turning.
8. Memory function. The top indicator lights flash for 20 sec. after a bite. If a bite was toward the bank, the right light indicator flashes.
9. 1-minute silent mode. Press the M button for about 2 seconds to turn on/off the silent mode. The alarm does not beep and sends no signal to the receiver when you place the rod on it. When the transmitter is turned off this mode is turned off automatically.
10. Connect mode. Press M and F buttons simultaneously to turn on/off the connect mode. When this function is activated, the transmitter transmits to the receiver the signals every 5 seconds. If the signal transmission to the receiver is interrupted for some reason (low battery, malfunction, theft, etc.), the receiver will send out a specific alarm signal for 5 seconds, and the LED corresponding to the transmitter will light up. When the transmitter is turned off this mode is turned off automatically.
11. Anti-theft function. Press the F button, the horn will beep twice. If someone picks up the rod from the alarm, it will send the signal to the receiver. The receiver horn beeps rapidly for 5 seconds, corresponding indicator light flashes rapidly. When the transmitter is turned off this mode is turned off automatically.
12. Press the toggle switch to turn off the alarm.

Receiver

1. Power on. Rotate the V wheel clockwise (to division 1) to turn on the receiver. All the indicator lights will flash twice; also the horn will beep twice.
2. Volume Adjustment. Rotate the V wheel to adjust the volume. 5 levels of volume + silent mode are available to adjust.
3. Tone selection. When the device is in standby mode the alarm tone of the receiver is synchronized with the alarm tone selected on the alarm.
4. Color select. The receiver is equipped with 6 full-color lights. When the device is in standby mode the alarm color of the receiver is synchronized with the alarm color selected on the alarm.
5. Vibration mode. Press the Z button to turn on/off the vibration mode. It can work without sound (2 divisions on the V wheel scale) or with sound (other divisions).
6. Synchronization mode. Press and hold down the A button for 3 seconds, and release it after a beep. The first light indicator will turn on. Rotate the transmitter roller wheel, so the receiver will receive the signal. If the transmitter is blue, the receiver will automatically switch to blue light pairing and flash. The sound will beep. Then the second indicator light will turn on. Rotate the second transmitter roller wheel and repeat the previous operation. Press R or Z button to exit the matching code. You can exit the matching code mode if there is no operation within 12 seconds.
7. Code erasing. Long press the A button for 3 seconds. After a beep continues pressing for another 3 seconds. After 3 beeps all the codes will be erased.
8. Drop-back function. The horn indicates drop/back bites with different sounds. Corresponding indicator light flashes.
9. Memory function. When you press the R button the LED that was on for the last alarm will light up again for 20 seconds. If a bite was toward the bank, the light indicator flashes.
10. Low voltage alarm. When the battery voltage is lower than 6.3V, the first light indicator will flash every 5 seconds. Replace the battery as soon as possible.
11. Power off. Rotate the V wheel to division 0 on the scale.

Specifications

Batteries: 6F22 (9 V) – alarms and receiver
Wireless receiving working frequency: 433 MHz
Operation distance of wireless receiver: 200–220 m
Dustproof and waterproof (IP 66)

If you don't use the devices for a long time, please take out the battery!